



ITOWA Stock List

Part No : 00F4DE
Part No : 00F4E2
Part No : 00F4E4
Part No : 1310104
Part No : 16
Part No : 16/4SA NS 0412225 CODE D229
Part No : 227177751
Part No : AACG7V2UV01
Part No : AACG7V2UV01-FC1
Part No : BATTERY BT7223MH
Part No : BOGGY 12/ 4
Part No : BOGGY 12/246
Part No : BOGGY8/166
Part No : BOGGY8166
Part No : BT3613MH
Part No : BT3613MH3A
Part No : BT3613MH3A2
Part No : BT7216MH
Part No : BT7223MH
Part No : Cover
Part No : GCFI4 48/230
Part No : Itowa Combi Joystick
Part No : KITINT2F
Part No : KITINT3R
Part No : KITPULSCBV02
Part No : KITSELMA

Part No : KTACC001V01

Part No : MC972104CS

Part No : MN2002

Part No : Mini Push Buton

Part No : PWM BT7223MH

Part No : RCMG1GNC000 RC COMBI 18 IT3R16 + CBX0309V00 CONF

Part No : RCMG1GNC000 - RC COMBI 18 GT JASO IT3R16+CBX0309V00

Part No : RX06

Part No : push button-- remote control--joystick